

# Bedworks Bookcase Headboard Assembly Instructions:

HARDWARE	
6	Barrel Nuts
4	Allen Bolts
1	4mm Allen Wrench
1	5mm Allen Wrench
4	Long Dowels
4	Short Dowels
2	15" Threaded Rods
2	Allen Bolt Caps

